

RS-232 communication setting

(*) next to an option indicate the default setting.

- Baud Rate



1200bps



2400bps



4800bps



* 9600bps



19200bps



38400bps

- Data bit



7 bits



* 8 bits



Default

- Stop bit



* 1 stop bit



2 stop bits



Check Version

- Parity



* None



Odd



Even



Mark



Space

BARCODE SCANNER

Quick Start Guide

Many thanks for choosing enjoy id product for more product information please visit www.enjoyid.it

How Do You Program Your Scanner?

1. Scan Start Configuration
2. Scan all necessary labels for parameters that meet your applications.
3. Scan End Configuration to end the programming.



Start Configuration



End Configuration

Resetting the Standard Product Defaults

If you aren't sure what programming options are in your scanner, or you've changed some options and want the factory settings restored, scan the bar code below.



Standard Product Default Setting

Italian Pharma Code

In this mode the decoded data characters are translated to the Italian Pharmaceutical format



Enable



*Disable

Interface Selection

The scanner is designed to switch easily from interfaces. Remember to reset the interface before changing to PS/2 or RS232 or USB cable.



* KEYBOARD



RS-232



USB

Emulate External Keyboard

Scan the barcode below if you do not have an external keyboard. After scanning the Emulate External Keyboard bar code, you must power cycle your computer.



Enable



* Disable

Language for keyboard interface

(*) next to an option indicate the default setting.



Italian



* US

Scanning Mode Selection

(*) next to an option indicate the default setting.



* Good Read Off



Trigger On/off



Testing Mode



Flash Mode



Continuous/Trigger off



Continuous/LED always on

Terminator selection - Keyboard & USB

(*) next to an option indicate the default setting.



None



* CR



Tab



ESC



CR+LF